



SYMBOL	DESCRIPTION
DMS	DOWN MAIN SOLENOID
DLS	DOWN LEVELING SOLENOID
ULS	UP LEVELING SOLENOID
UDS	UP DUMP SOLENOID
DA	DOWN ACCELERATION
DT	DOWN TRANSITION
DC	DOWN CLOSING
DL	DOWN LEVELING
DM	DOWN FULL SPEED
BP	EYPASS
UL	UP LEVELING
UA	UP START
UT	UP TRANSITION
UD	UP DUMP

			ELEVATOR EQUIP. CO. 4035 GOODWIN, L.A.
			UV 5A SCHEMATIC
11-23-75	REWORK		DATE 11-73